












QUICKSTART









Leica DISTO™ D8



- | Buttons | |
|---------|---------------------------------------|
| 1 | ON / DIST (On/measuring) |
| 2 | Digital Pointfinder |
| 3 | Timer |
| 4 | Plus (+) |
| 5 | Minus (-) |
| 6 | Area/volume |
| 7 | Ind. measurement (Pythagoras) |
| 8 | Trapezoid |
| 9 | Functions |
| 10 | Reference |
| 11 | Storage/Memory |
| 12 | Clear / Off |
| 13 | Menu/Equal |
| 14 | 2nd for navigation |
| 15 | Ind. measurement (inclination sensor) |
| 16 | Bluetooth activate |

- when it has to be right





LASER RADIATION – DO NOT STARE INTO BEAM
620-690nm/0.95mW max.
CLASS II LASER PRODUCT



HERBERT KREITEL
Feinmechanische Werkstätten
Vermessungs-, Navigations-
und Kontrollinstrumente
Inh. Norbert Kreitel
Taunusstrasse 30
53119 Bonn
Germany
Tel. +49 (0) 2 28 65 47 60
Fax +49 (0) 2 28 69 74 93
www.kreitel-vermessungsgeraete.de
info@kreitel-vermessungsgeraete.de

www.disto.com



SAP. No. 766553b

